

©2010 Research In Motion Limited. All rights reserved. BlackBerry", RIM", Research In Motion", Sure Type", SurePress" and related trademarks, names and logos are the property of Research In Motion Limited and are registered and/or used in the U.S. and countries around the world. Mac is a trademark of Apple Inc. Bluetooth is a trademark of Bluetooth Sic. Hotmail, Windows, Windows Live, and Windows Mobile are trademark of Microsoft Corporation. Palm is a trademark of Palm Trademark Holding Company, LLC. Wi-Fi and Wi-Fi Protected Setup are trademarks of the Wi-Fi Allilance. All other trademarks are the property of their respective owners. This documentation is provided "asis" and without condition, endorsement, guarantee, representation or warranty, or liability of any kind by Research in Motion Limited and its affiliated companies, all of Which are expressly disclaimed to the maximum extent permitted by applicable law in your jurisdiction.

MAT-32970-001 | PRINTSPEC-089 | SWD -1015817-0709091317-001 | RDA71UW/RDB71UW/RCL22CW

BlackBerry.

Safety information

IT IS IMPORTANT THAT YOU READ THE SAFETY AND PRODUCT INFORMATION BOOKLET (INCLUDED) PRIOR TO USING YOUR BLACKBERRY® DEVICE. It contains essential safety information related to your device.

More tips, interactive demos, and videos are online!

For more info, go to www.blackberry.com/gettingstarted.

Insert the SIM card and battery


Depending on your BlackBerry® device model or your wireless service provider, you might not need to insert a SIM card to use your device.











Insert a media card

You can use a media card to store more media files. A media card might already be inserted in your BlackBerry® device.










The setup wizard can help you get started quickly.

- Set up email addresses
- Learn about navigation and typing
- Personalize your device
- Set up wireless and Bluetooth® connections

If the setup wizard does not appear automatically, on the Home screen or in the **Setup** folder, click the **Setup Wizard** icon.



- . On the Home screen or in the **Setup** folder, click the **Setup Wizard** icon.
- 2. On the **Email Setup** screen, select one of the following options:
- I want to create or add an email address: This option is most common for individual users. Use this option to associate your BlackBerry® device with one or more existing email accounts (for example, Windows Live™ Hotmail®), to create a new email address for your device, or to use a social networking application. If this option does not appear, contact your wireless service provider.
- I want to use a work email account with a BlackBerry Enterprise Server: This option is most common for corporate users. If your administrator gave you an enterprise activation password, use this option to associate your device with your work email account using the BlackBerry® Enterprise Server.
- Click Next, and complete the instructions on the screen.

Note: When your email address is set up correctly, you receive a confirmation message. To see your email messages, on the Home screen, click the Messages icon.

I cannot set up an email address

- In the **Setup** folder, click the **Setup Wizard** icon. On the **Email Setup** screen, verify that your email address information is correct. To view your password, select the **Show Password** check box.
- Verify with your wireless service provider that your email account type is supported.
- Verify that you have switched devices correctly.

For information about setting up an email address, visit www.blackberry.com/go/docs and click BlackBerry Internet Service.

Switch devices

If you are switching from a BlackBerry® device that is associated with an existing email address (for example, Windows Live™ Hotmail®) to a new BlackBerry device, do the following:

- 1. On your computer, open the BlackBerry® Desktop Manager. Use the Device Switch Wizard to transfer data from your previous device to your new device.
- 2. On your new device, on the Home screen or in the **Setup** folder, open the email setup application and follow the prompts. If you do not receive the prompts or if you decline any of the prompts, email messages will not be sent to your new device until you switch devices manually. If you are selling or buying a previously owned BlackBerry device that operates on CDMA networks, contact your wireless service provider to switch devices.
- 3. Delete the data from your previous device by doing a security wipe. For more information, see the user guide for your device.

You can also import data from your previous Palm® device or Windows Mobile® powered device to your new BlackBerry device using the BlackBerry Desktop Manager.

View applications



Home screen

More icons on the Home

screen

Press the **Menu** kev View more icons on the Home screen Press and hold the Menu

Switch between applications

key and then click an application

Applications

Get started with some of these great applications.



Messages

Send your messages.



Contacts

Add new contacts.



Browser

Visit web pages.



Media

View saved pictures, play songs, and more.



Camera (if supported)

Take a picture.



Chat with friends or colleagues.



Downloads

Find downloaded applications here or in other folders, such as Games.



Options

Set your device options. You can find more options in each application menu.




Manage Connections

Set up wireless connections, such as a Bluetooth® connection.








Find answers here or click **Help** in a menu.



opened message sent message







- 1. On the Home screen, click the Messages icon.
- Press the key > Compose Email.
- 3. In the **To** field, type an email address.
- 4. Type a message.
- 5. Press the key > **Send**.

BlackBerry Messenger 🕮

BlackBerry® Messenger helps you stay connected with friends or colleagues who have a BlackBerry device. Keep in touch by sending instant messages, updating your status, and more.

Change your ring tone

- 1. From the Home screen, press the key.
- 2. Press the key > Set Ring Tone.
- 3. In the Ring Tone field, click a preloaded ring tone, or click **Select Music** at the top of the list.
- 4. Press the key > Save.

Download a ring tone

- 1. On the Home screen, click the **Media** icon > **Ring** Tones icon.
- 2. Press the key > Download Ring Tones.

Additional data charges might apply. For information, contact your wireless service provider. If this feature is not available, you can download ring tones from other web sites.

Pair with a Bluetooth enabled device (



You must pair your BlackBerry® device with the Bluetooth® enabled device before you can connect to it. For information about preparing a Bluetooth enabled device for pairing, see the documentation for that device.

- 1. On the Home screen, click the **Manage Connections** icon.
- 2. Click **Set Up Bluetooth** > **Search**.
- 3. Click a Bluetooth enabled device.
- 4. If necessary, do one of the following:
- If the Bluetooth enabled device does not have a keyboard, on your BlackBerry device, type the pairing passkey that is in the documentation that came with the Bluetooth enabled device.
- If the Bluetooth enabled device has a keyboard, type a pairing passkey of your own choosing on both devices.

Visit a web page

Depending on your wireless service provider, multiple browsers might appear on your BlackBerry® device. For information about the charges associated with using each browser, contact your wireless service provider.

- 1. On the Home screen, click the **Browser** icon.
- If a web address field appears on the screen, type a web address.
- If a web address field does not appear on the screen, press the key > **Go To**. Type a web address.
- 2. Press the wkey.

Take a picture 👸

- 1. On the Home screen, click the Camera icon.
- 2. To zoom in to or out from a subject, slide your finger up or down on the trackpad.
- 3. Click the trackpad.

Record a video

- 1. On the Home screen, click the **Media** icon > **Video** Camera icon.
- 2. Click the trackpad.
- 3. To pause recording, click the trackpad again.

Connect to a Wi-Fi network (প্রে)

- 1. On the Home screen, click the **Manage Connections** icon.
- 2. Click Set Up Wi-Fi Network.
- 3. Do one of the following:
- Click Scan for Networks. Click a network.
- Click Manually Add Network. Type the network name. Click Add.
- If you are using a wireless access point or router that is enabled with Wi-Fi Protected Setup™, click Push Button Setup.
- 4. Complete the instructions on the screen.
- 5. Click Finish.

Change your wallpaper

- 1. From the Home screen, press the key.
- 2. Click Options > Wallpaper.
- To take a picture, click Camera. Click the camera icon.
- To select a picture that you took, click the picture.
- To select a preloaded picture, click **Preloaded Pictures.** Click a picture.
- 3. Press the key > Set As Wallpaper.
- 4. Press the key twice to return to the Home screen.

Download applications and themes

You can download applications, themes, and ring tones from your wireless service provider's web site (if available) or from the BlackBerry App World™ storefront. To download a theme, do the following:

- 1. On the Home screen or in a folder, click the **Options** icon.
- 2. Click Theme.
- 3. Press the key > Download Themes.

Your wireless service provider must support this feature.

Additional data charges might apply. For information, contact your wireless service provider.

BlackBerry Desktop Software

You can use the BlackBerry® Desktop Software to back up and restore BlackBerry device data and synchronize calendar appointments, music, pictures, and more between your device and computer.



To download the BlackBerry Desktop Software, visit www.blackberry.com/desktopsoftware.

Synchronize your media files

- 1. Connect your BlackBerry® device to your computer.
- On your computer, open the BlackBerry® Desktop Manager.
- If you are using a Windows® computer, click **Media**.
- If you are using a Mac computer, in the Media section in the left pane, click Music. Mac users can synchronize only music.

For more information, see the help in the BlackBerry Desktop Manager.

Get help

- www.blackberry.com/gettingstarted: Find getting started information.
- Your wireless service provider web site: Find information about your wireless network or wireless service plan.
- www.blackberry.com/go/ declarationofconformity: View the Declaration of Conformity made under Directive 1999/5/EC (HG nr.88/2003).

CAUTION: Use only those accessories approved by Research In Motion. Using any accessories not approved by RIM for use with this particular device model might invalidate any approval or warranty applicable to the device, might result in the non-operation of the device, and might be dangerous.